## resideo Automatic air vent

# Braukmann E125S

Automatic air vent for solar installations

## **APPLICATION**

The E121 Air Vent is a reliable automatic venting device and is suitable for venting of air or gas from heating systems or heat process installations.

Air in heating systems and other fluid-filled systems frequently causes disruptions in water cycles, as well as corrosion and noise. Therefore pay particular attention to a good ventilation.

#### **SPECIAL FEATURES**

- Absolutely drip free
- Long-term reliability
- High ventilation capacity
- Cleaning or exchange of the sealing and internal parts after additional installation of the AVSOLAR shut-off valve is possible without emptying the system
- Extremely quick reaction
- Particularly compact




#### **TECHNICAL DATA**

Media					
Medium:	Water or water-glycol mixture, quality according to VDI 2035 (up to 50 % glycol)				
Operating temperatures					
Max. operating temperature medium:	150 °C*				
Pressure values					
Max. operating pressure:	0.5 - 10 bar				
Nominal pressure:	max. 18 bar				
Connections/Sizes					
Connection sizes:	$\mathrm{G}^{3}/\mathrm{8}^{"}$ or $\mathrm{G}^{1}/\mathrm{2}^{"}$				

<sup>\*</sup> Not suitable for steam.

## **CONSTRUCTION**



#### **METHOD OF OPERATION**

Inside the automatic air vent there is a floater which operates a lever according to the water level. When there is no water in the housing, then the floater opens the valve. Air can therefore be vented from the heating system during filling. When the heating system has been filled, the inflowing water closes the valve and the vent is shut-off. Water usually contains oxygen which bubbles off during operation of the system and collects at the highest point. The automatic air vent must therefore be fitted at the air collection position (highest point on a boiler or pipework circuit).

#### TRANSPORTATION AND STORAGE


Keep parts in their original packaging and unpack them shortly before use.

The following parameters apply during transportation and storage:

Parameter	Value
Environment:	clean, dry and dust free
Min. ambient temperature:	5°C
Max. ambient temperature:	90 °C
Min. ambient relative humidity:	25 % *
Max. ambient relative humidity:	85 % *

<sup>\*</sup>non condensing

## **DIMENSIONS**



Parameter		Values		
Connection size:	G	<sup>3</sup> / <sub>8</sub> "	1/2"	
Dimensions:	Н	98	98	
	h <sub>1</sub>	87	87	
	h <sub>2</sub>	10.5	10.5	
	D	48	48	
	L	72.5	72.5	
Wrench size:	SW	23	27	
Weight:	kg	2.60	2.95	

Note: All dimensions in mm unless stated otherwise.

## **ORDERING INFORMATION**

The following tables contain all the information you need to make an order of an item of your choice. When ordering, please always state the type, the ordering or the part number.

#### **Options**

The valve is available in the following sizes:  $G^{3}/8$ ",  $G^{1}/2$ ".

- standard
- not available

		E125SA
Connection sizes:	Standard version	•

Note: ... = space holder for connection size

Note: Ordering number example for  $^{1}/_{2}$ " and type A valve: E125S-1/2A

#### **Accessories**

	Description		Dimension	Part No.
	AVSOLAR	Shut-off valve		
		Brass housing, high-grade, temperature-resistan resistant elastomer sealing ring	t plastic internal	parts, hot water-
		Size: <sup>3</sup> / <sub>8</sub> "		AVSOLAR-3/8
		Size: 1/2"		AVSOLAR-1/2